



Instruction for the Laundry Tub Overflow Kit

1. Drill or Punch a 30mm Diameter Hole in the Tub at the desired location.
2. The Stainless Steel Face of the Overflow Connector is bedded on the inside of the Tub using a suitable sealant. Ensure it is the correct way round.
3. The Body and the Rubber Washer of the Overflow Connector are placed on the outside of the tub and then attached / tightened with the Stainless Steel Bolt.
4. The Flexible Hose is then attached to the Spigot of the Overflow Connector and secured with a Stainless Steel Worm Drive Clamp (not included).
5. The lower end of the Flexible Hose is then connected to the Branch Line of the Rinse By-Pass junction (part of the Milena By-Pass Kit) or similar appropriate Branch Line. This is again secured with a Stainless Steel Worm Drive Clamp (not included).

NOTE:

The Branch Line will need to be drilled out to allow for the passage of the overflow water.



www.milena.com.au